

Installation Instructions for the DS7420i Dual Phone Line/Bell Supervision Module

Table Of Contents

1.0 Description.....	1
2.0 Specifications.....	1
3.0 Installation.....	1
4.0 Operation.....	2
5.0 FCC Compliance Notice.....	3
6.0 FCC Phone Connection Notice to Users.....	3
7.0 Canadian Department of Communications.....	3
8.0 Wiring Diagram.....	4

1.0 Description

The DS7420i is an accessory board designed for use with the DS7400Xi control/communicator. It allows the control to be used in NFPA 72 installations. The DS7420i provides two supervised 12 VDC signaling outputs, one Class A (Style D) input zone, and dual phone line transmission and supervision.

- System is Power Limited except for battery terminals. All wiring entering this enclosure must be power limited.
- FCC registration number: ESVUSA-20294-KX-N
- DOC number: 1249 5895 A

2.0 Specifications

- **Auxiliary Power Requirements:** Supervisory: 12 VDC, nominal, 20 mA. Alarm: 140 mA.
- **Indicating Appliance Circuit (Bell Output):** 12 VDC, special application supervised output supplies up to 1.75 A for vibrating bells.
- **Auxiliary Output Circuit:** 12 VDC, special application supervised output latches on alarm and resets upon system reset. It is intended for strobes/indicating appliances and supplies up to 1.0 A.
- **Initiating Device Circuit (terminals 13-16):** The Class "A" loop is intended for connection of Normally Open (closed on alarm) dry contact initiating devices such as waterflow switches.

The Class "A" loop will not support loop powered devices such as two-wire smoke detectors.

- **Maximum Loop Resistance:** Class "A" loop tolerates a maximum loop resistance of 150 ohms total.
- **Operating Temperature:** +32° to +120°F (0° to +49°C)
- **Ringer Equivalence Number (REN) = 0.1B**

3.0 Installation

The DS7420i should be mounted within a DS7400Xi enclosure. For programming information, refer to the *DS7400Xi Reference Guide* (P/N: 40816 for Ver. 4+, P/N: 28995 for Ver. 3+) .

NOTE: The DS7400Xi control must be installed in accordance with NFPA 72 guidelines.

3.1 Hardware Installation

- Disconnect power from the control panel. Unplug the transformer and remove the red battery lead.

NOTE: For Commercial Fire applications, the TR1850 transformer (Basler Electric BE116250CAA) must be enclosed in the AE-TR16 Transformer Enclosure. The wiring from the AE-TR16 to the control and the wiring to the outlet box in conduit must also be enclosed in the AE-TR16.

- Mount the DS7420i Module in the enclosure as shown on page 4. Use the supplied mounting clips and screws.

3.2 Internal Wiring

- Connect internal wiring as shown on page 4.
 - Connect the options bus of the DS7420i (terminals 1-4) to the options bus of the control panel.
 - Connect the battery input (terminals 5 and 6) to the control panel battery using the dual battery clips provided.
 - Connect the control line phone input (terminals 21-24) to the phone line output (13-16) of the DS7400Xi.
 - If using the Class "A" zone, connect the zone input terminals (11 and 12) to the zone 1 input (19 and 20) of the control panel.

Note: The DS7420i is fixed as address 15 on the control options bus. If you are using a DS7400Xi Rev. 3 control/communicator, keypad 15 will not be available for system use. See your DS7400Xi Reference Guide.

4.0 Operation

4.1 Normal Condition

Under normal conditions, the keypad Power and Status Lights will be on steady.

4.2 Fire Alarm

During a fire alarm, the alarm sounding devices and the keypad sounders will be activated. The keypad display will read "Fire Alarm."

- **To silence the fire alarm sounders:**

Enter a valid PIN followed by the [Off] key. "Fire Alarm" and "Sounder Silenced" will then be displayed.

- **To reset the system:**

Determine the cause of the alarm. Then enter a valid PIN followed by [System Reset]. This command clears the "Fire Alarm" and "Sounder Silenced" displays.

NOTE: The control must be reset after a fire alarm or future alarms will not be detected.

4.3 Fire Trouble

During a fire trouble (e.g. open on a Class A loop, open on any fire loop), the keypad sounders will pulse once every 10 seconds. The keypad display will read "Fire Trouble" with a zone number. A fire trouble with no zone number indicates a ground fault.

- **To silence the sounders:**

Enter a valid PIN followed by the [Off] key.
If the cause for the Trouble condition has been eliminated, the sounders will silence and the "Fire Trouble" display will be cleared.

If the cause for the Trouble condition has not been eliminated, the sounders will silence, but the "Fire Trouble" display will not be cleared. The keypad will also display the zone that is in the Trouble condition.

- **To clear the display:**

Eliminate the cause of the Trouble condition. Then enter a valid PIN followed by the [Off] key.

4.4 Supervisory Signal

During a Supervisory Signal (e.g. wiring to supervisory zone has been shorted), the keypad sounders will pulse once every 10 seconds. The keypad display will read "Supervisory" with a zone number.

- **To silence the sounders:**

Enter a valid PIN followed by the [Off] key.
If the cause for the Supervisory condition has been eliminated, the sounders will silence and the "Supervisory" display will be cleared.

If the cause for the Supervisory condition has not been eliminated, the sounders will silence, but the "Supervisory" display will not be cleared.

- **To clear the display:**

Eliminate the cause of the Supervisory condition. Then enter a valid PIN followed by the [Off] key.

4.5 Control Trouble

During a Control Trouble, the Power Light will be flashing and the keypad sounders will pulse every ten seconds. The keypad display will read "Control Trouble/Press #87."

A Control Trouble can be caused by several conditions.

- **To silence a Control Trouble:**

Enter a valid PIN followed by the [Off] key.

- **To determine the cause of the Control Trouble:**

Enter a valid PIN followed by [#] [8] [7]. One of the following will be displayed:

- **AC Failure:** AC power has been lost or has gone below the "Brown Out" level. The Power Light will continue to flash until AC power has been restored. If AC power restores while the Trouble condition has been silenced, the sounders will begin to pulse again.
- **Low Battery:** The battery voltage has dropped below 12 VDC or the battery is missing. The Low Battery condition may be cleared, but will return if the battery fails the next battery test. After clearing a Low Battery condition, the battery should immediately be tested as described in the "Testing Procedure" section below. If the battery restores while the Trouble condition has been silenced, the sounders will begin to pulse again.
- **Bell Trouble:** The bell circuit wiring is open or shorted. The keypad sounders will pulse once every 10 seconds (if in Commercial Fire Mode). The keypad display will read "2Ph/Bell Fault."

To silence the sounders, enter a valid PIN followed by the [Off] key. If the cause for the Trouble condition has been eliminated, the sounders will silence and the "2Ph/Bell Fault" display will be cleared.

If the cause for the Trouble condition has not been eliminated, the sounders will silence, but the "2Ph/Bell Fault" display will not be cleared.

- **To clear a Control Trouble:**

Eliminate the cause of the Trouble condition. Then enter a valid PIN followed by [System Reset].

4.6 Testing Procedure:

The sounders should be tested (at least weekly) using the keypad activated Sounder Test.

The Sounder Test is activated by entering a PIN followed by [#] [8] [5]. This test activates the sounders using power from the battery, thereby, testing the battery. If the battery is defective, the system will go into a Control Trouble condition. The system sirens and keypad sounders will activate for two seconds.

5.0 FCC Compliance Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

6.0 FCC Phone Connection Notice To Users

This control complies with Part 68 of the FCC rules. On the top of the PCB is a label that contains, among other information, the FCC Registration Number and the Ringer Equivalence Number (REN) for this equipment. You must, upon request, provide this information to your local telephone company. The REN is useful to determine the quantity of devices that you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices that you may connect to your line, you may want to contact your local telephone company to determine the maximum REN for your local calling area.

This equipment may not be used on coin service provided by the telephone company. This control should not be connected to party lines.

Should this equipment cause harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advanced notice isn't practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

If you experience trouble with this equipment, please contact the manufacturer for information on obtaining service or repairs. The telephone company may ask that you disconnect this equipment from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning. The repairs to this equipment must be made by manufacturer and not by the user.

To guard against accidental disconnection, there is ample room to mount the Telco jack to the inside of the Control cabinet.

The operation of this Control may also be affected if events such as accidents or acts of God cause an interruption in telephone service.

7.0 Canadian Department of Communications

General Installation Requirements:

Notice: The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network, protective, operational, and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction. Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure, for their own protection, that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Terminal Requirements:


The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device, to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all the devices does not exceed 100. The Load Number of the DS7420i is 2.

RFI Requirements:

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

[Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.]

8.0 DS7420i Wiring Diagram



- All input and output connections are inherently low voltage, power limited. Use U.L. Listed power limited cable only.
- This equipment is to be installed in accordance with NFPA Standard 72.
- The control panel compatibility identifier is C.